
PR-201 Runouts for Resurfacing

(This section last updated 05-15-14)

The use of surface runouts (Type 'R1' and Type 'R2') is generally limited to the case below:

1. No other milling is required on the project and the relative cost to mobilize a milling machine is excessive, and
2. There is evidence that using surface runouts in similar situations have yielded good results.

This case may appear on smaller resurfacing projects, such as MP projects or resurfacing at spot locations.