

[112-6](#) Bridge Approach Section

(This section last updated 11-16-16)

All paved shoulder panels are to be included on Tabulation [112-9](#). The square yard areas for the approach pavement in single reinforced and non-reinforced areas should only account for the widths of driving lanes.

Review project with the Bridges and Structures Methods Engineer to determine the appropriate abutment, approach, and abutting pavement types.

Special backfill is used only with [BR-241](#).