



- Notes:
- ① Install hook bar at 12" intervals with top projecting so as to clear the paving equipment and as near the false form board as possible to maintain 2" surface clearance.
 - ② 2" x 4" False Form.
 - ③ Excavate a slight cavity in concrete around each bar.
 - ④ 12" maximum for Standard 6" Curb.
16" maximum for Sloped 6" Curb.